

AIRPORT DIAGRAM

BELLINGHAM INTL (BLI)
BELLINGHAM, WASHINGTON

AL-45 (FAA)

ATIS
134.45
BELLINGHAM TOWER ★
124.9 379.3
GND CON
127.4 379.3

D

ELEV
163

9L

B
B
B
A
C
D
E
F
F
F
V
A
F
A
F
A

162.4°

48°48.0'N

RWY 16-34
S-75, D-160, 2S-175, 2D-250

COMMERCIAL
AIRCRAFT
PARKING

COMMERCIAL
TERMINAL
US
CUSTOMS

TWR
247

FBO/GENERAL AVIATION
TERMINAL

TRANSIENT
PARKING

GENERAL AVIATION
HANGARS

FIRE
STATION

HANGAR

FIELD
ELEV
170

6701 X 150

342.4°

NOTE: THIS AREA NOT VISIBLE
FROM TOWER

48°47.0'N

122°32.5'W

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

122°32.0'W

122°31.5'W

NW-1, 07 APR 2011 to 05 MAY 2011

NW-1, 07 APR 2011 to 05 MAY 2011



JANUARY 2010
ANNUAL RATE OF CHANGE
0.2° W

AIRPORT DIAGRAM

BELLINGHAM, WASHINGTON
BELLINGHAM INTL (BLI)